



Installation Guide Thermal Overload Relay Types TI 80 and TI 86

520B5503

520B5503



During assembly or commissioning check control circuit by pressing test lever and reset button.